

# Plumbed Eyewash Station Checklist

## Weekly checklist

For workplace first aid products, visit [steroplast.co.uk](http://steroplast.co.uk)



Company name .....

Location .....

	Date	Date	Date	Date	Date	Date	Date	Date	Date	Date	Date	Date
Do eyewash units turn on when activated?												
Is there any visible leaking?												
Is the eyewash station well lit?												
Is the eyewash station visibly signposted?												
Is the station free from obstructions?												
Can the station wash both eyes simultaneously?												
Does the unit allow the user to hold their eyes open without spraying more than 8" above the nozzles?												
Are the nozzles protected with caps?												
Do the caps release with the flow of water?												
Can the station deliver a minimum of 0.4 gallons of water per minute for 15 minutes?												
Is the water flow a minimum of 33-53 inches from the floor and at least 6 inches from a wall or the nearest obstruction?												
Does the hands-free stay-open valve activate in one second or less?												

An emergency eyewash station weekly inspection checklist is necessary to ensure your eye first aid facilities are always in good working condition and ready to be used at all times. This checklist has been created in accordance with ANSI Z358.1-2014 guidelines.

**For station refills, visit [steroplast.co.uk](http://steroplast.co.uk)**